

Recycled Rubber

Maintenance Instructions - Indoor Applications

1/1/2025

1. Initial Cleaning	<p>1.) Remove all loose debris by vacuuming, sweeping or using a dust mop.</p> <p>2.) Scrub floor by using a buffer or auto scrubber fitted with a soft nylon brush or purple scrub pad. The floor can also be scrubbed using a traditional string mop or newer style microfiber mop head. We recommend using Diversey brand "Profi" for cleaning and maintenance but any neutral ph (7-9) is acceptable to use on the floor. Dilute the solution with water per the manufacture's instructions. Do not flood the floor with water.</p> <p>3.) Use a wet vacuum to pick up the cleaning solution from the floor and rise with clean water. Again, do not flood the floor. The rinse water should then be wet vacuumed from the floor.</p> <p>4.) Allow the floor to dry before foot traffic.</p>
2. Regular Maintenance	<p>1.) Keep surface free from loose debris by sweeping, using a dust mop or by vacuuming the surface daily or as needed.</p> <p>2.) Damp mop surface by using a traditional mop, microfiber mop or by using an auto scrubber fitted with a purple scrub pad. Use the Diversey brand "Profi" as the detergent and dilute with water per the manufacturer's instructions.</p> <p>3.) Use a wet vacuum to pick up the cleaning solution from the floor and rise with clean water. Again, do not flood the floor. The rinse water should then be wet vacuumed from the floor.</p> <p>4.) Allow the floor to dry before foot traffic.</p>